### AIR INTELLIGENCE AGENCY HANDBOOK 33-102 30 NOVEMBER 2000

Communications and Information

# ENGINEERING AND INSTALLATION STANDARD

**NOTICE:** This publication is available digitally on the SAF AFDPO site at:

Supersedes AIAH 33-102, 5 March 1999. OPR 668 LS/ILES (Mr. Jimmie Davis)

Certified by 690 IOG/CC (Col Gilly A. Marshall)

Pages: 165/Distribution: F

This Engineering and Installation Standard (EIS) standardizes installation practices necessary to install equipment and systems in HQ Air Intelligence Agency facilities. For technical information and installation procedures, see the appropriate section in the EIS. Applicable guidance was extracted from Air Force 31 series Technical Orders, the National Electrical Code and Commercial Publications; use these references and good engineering practices when specific details are not contained herein. The use of brand or trademark names in this publication are incidental and do not imply endorsement by any government agency. To make suggestions for corrections or improvements to this document send comments to:

668LS/ILES FAX (210)977-2983

2 Hall Blvd, Suite 108 FAX DSN 969-2983

San Antonio TX 78243-7034 PHONE DSN 977-2935

Comments should include, but not be limited to, drawing number, drawing date, EIS page number, narrative description of suggestion and references for suggested change. Include as much information as possible to make the suggestion understandable.

#### Summary of Revisions

Added references for TEMPEST requirements and updated drawings listed below.

## **Updated drawings:**

A024-1, -F325-2, -F325-3, -F325-5, -F331-1, -F331-2, -F333-1, -G289-1, -M228-1, -P018-1, -P018-2, -P328-1, -P332-1, -P342-2 -P342-5

- 1. General Information. Electrical technical power and interposition cable distribution at AIA facilities are either suspended overhead or routed under raised flooring. Installation scheme specifies methods and materials. There are National Electrical Code requirements for wiring and cabling methods in ducts, plenums, and other environmental air-handling spaces. When overhead, cable troughs are supported by hangers attached to a steel channel grid secured to the ceiling. Electrical bus ways are attached below the cable trough. When inter-position cabling and electrical power (enclosed in flexible conduit) under raised flooring, lay on the sub-floor, cabinets are grounded either to a ground bus routed through the overhead trough or attached to a steel channel grid below the raised floor. Cabinets are anchored either with studs secured to a hard floor or through a raised floor to the anchoring grid and secured to the sub-floor.
- 2. Signal Cable Installation. Interposition cable is laid directly on the sub-floor. If routing is not specified in the installation scheme lay cables either in line or at right angles to cabinet rows. Maintain separation from power runs and cross at right angles when possible. Pull in enough slack to allow for forming and wiring. Orderly routing and a good appearance should be maintained throughout. Excess cable will be eliminated and not left in coils beneath the raised flooring. This is consistent with good engineering practices. Entry openings in raised floors or plenums will be air sealed using firestop putty or other material to prevent air from escaping.

- 3. Flex conduit Installation. Fused panels and ducts extending beneath a raised floor for technical power are normally contractor or unit responsibilities. Power cabling is enclosed in flexible steel conduit from power panels to individual equipment cabinets. Conduit runs, which exceed 100 feet, must have pull boxes. If routing is not specified in an installation scheme lay conduit in line or at right angles to cabinet rows. Maintain separation from signal runs and cross at right angles when possible. Raised floor entry holes are sealed using firestop putty after installation. To reduce possible source of ignition below the raised floor, power receptacles and connectors are installed above the raised floor or in surface mounted access modules. Only equipment that is used for the sensing may have electrical power applied to them below the raised floor.
- **4. Yellow Equipment Ground Wire.** Only use yellow equipment ground wire when there are two separate grounding systems to reduce noise; one for the low frequencies system (Yellow Wire) and one for the high frequencies system (Green Wire). There must be no continuity between the systems except at the Grounding Electrode or Plate. For the Low Frequency System, ac protective ground must not be connected to the power panel, the cabinets must be electrically insulated from other devices. Refer to T. O. 31-10-24, Chapter 9, for more information.
- **5. TEMPEST References**. Air Intelligence Agency Instruction (AIAI) 33-203, *The AIA TEMPEST/EMSEC Security Program*, must be complied with when installations are within a SCIF. Air Force Systems Security Memorandum (AFSSM) 7011, *Emission Security Countermeasures Reviews*, provides guidance for non-SCI Facilities.

Note: (\*) indicates updated drawing.

| Title Category 01 – Communications                         | Drawing Number        | Page |
|--|-----------------------|------|
| GADFLI Interconnection Diagram                             | A021-1                | 7    |
| *Cable Labeling and Equipment Designator                   | A024-1                | 8    |
| Category 5 EIA/TIA 568A & B                                | A029-1                | 9    |
| Systems Interface ElIIP/FIX/PARSEC                         | A057-1                | 10   |
| AN/GYC-8 Interfaces  | A069-1                | 11   |
| COMM Interface ATT-5310 to CSPA                            | A076-1                | 12   |
| COMM Interface GYC8 CSPA                                   | A086-1                | 13   |
| COMM Interface DP2048 to CSPA                              | A091-1                | 14   |
| COMM Interface MUX to CSPA                                 | A092-1                | 15   |
| ASTW COMM Interface Connector Details                      | A351-1                | 16   |
| COMM Interface Streamliner IDF to AT&T 5310                | A369-1                | 17   |
| COMM Interface OPSCOMM IDF to AT&T 5310                    | A370-1                | 18   |
| COMM Interface IDF to ODS-318 Fiber Optic Multiplexer      | A371-1                | 19   |
| COMM Interface Wide Area Network IDF to Ethernet LAN       | A396-1                | 20   |
| DP2048 Synchro Port to CSPA                                | A401-1                | 21   |
| DP2048 Asynchro Port to CSPA                               | A402-1                | 22   |
| COMM Interface IDF to DP2048                               | A403-1                | 23   |
| DP2048 Statmux to CSPA odd/even Connector                  | A404-1                | 24   |
| IDF to Tidytips CS/1 Connections                           | A406-1                | 25   |
| COMM Interface ASTW to CSPA                                | A407-1                | 26   |
| COMM Interface 3B2 to FPA to Modem                         | A409-1                | 27   |
| Title Category 02—Antennas                                 | <b>Drawing Number</b> | Page |
| SSVS-879-1A Antenna Control Signal Flow and Wiring Diagram | B050-1                | 28   |
| SSVS-879-1A Antenna Switch Front Panel                     | B050-2                | 29   |
| SSVS-879-1A Antenna Switch Power                           | B050-3                | 30   |
| Antenna Cabling Cable Vault Details                        | B054-1                | 31   |
| Antenna Cabling  | B054-2                | 32   |

AIAH 33-102 30 NOVEMBER 2000 3

| Antenna Cabling Cable Labeling Requirements | B054-3 | 33 |
|---|--------|----|
| AN/FRD Matrix To Antenna Control Unit Cable | B058-1 | 34 |
| AN/FLR Beam Selector and Signal Flow        | B231-1 | 35 |
| ID MUX To OCU And Control S/S Cables        | B343-1 | 36 |
| DF Position To DF MUX and Gonio Matrix      | B343-2 | 37 |
| Antenna Control Cables Find Details         | B374-1 | 38 |
| Antenna Control Cables Pinning Details      | B374-2 | 39 |
| Antenna Control Cables Pinning Details      | B374-3 | 40 |
| SSLV Cabling Details                        | B375-1 | 41 |
| SSLV Cabling Details                        | B376-1 | 42 |
| LPM0 Cabling Details                        | B377-1 | 43 |
| BBH Cabling Details                         | B378-1 | 44 |
| SSLV Cabling Details                        | B379-1 | 45 |
| LP3 Cabling Details                         | B380-1 | 46 |
| AVW Cabling Details                         | B381-1 | 47 |
| SSLL Cabling Details                        | B382-1 | 48 |
| SSLV Cabling Details                        | B383-1 | 49 |
|   |        |    |

# Title Category 03 – 04 – 05 Deleted

| Title Category 06—Anchoring, Hanging, and Mounting                    | <b>Drawing Number</b> | Page |
|---|-----------------------|------|
| Raised Floor Cabinet Anchoring Detail General                         | F325-1                | 50   |
| *Raised Floor Cabinet Anchoring & Grounding Details                   | F325-2                | 51   |
| *Raised Floor Cabinet Anchoring Grounding Details - Hardware          | F325-3                | 52   |
| Raised Floor Cabinet Anchoring Details Cabinet Variations             | F325-4                | 53   |
| *Hard Floor Cabinet Anchoring   | F325-5                | 54   |
| *Raised Flooring Cutout Details (without under floor cooling)         | F331-1                | 55   |
| *Raised Flooring Cutout and Cooling Details Emcor Rack or General Use | F331-2                | 56   |
| *Raised Flooring Cutout and Cooling Details 12" X 6" Air Register     | F333-1                | 57   |
| Title Category 07—Local Area Network (LAN) and Fiber Ontics           | Drawing Number        | Раде |

| Title Category 07—Local Area Network (LAN) and Fiber Optics   | Drawing Number | Page |
|---|----------------|------|
| 1EEE 802.3 ETHERNET Over view                                 | G005-1         | 58   |
| 1EEE 802.3 ETHERNET Terms                                     | G005-2         | 59   |
| Attachment Cable Wire Connections                             | G005-3         | 60   |
| Attachment Cable Wire Connections                             | G005-4         | 61   |
| Attachment Cable Assembly Diagram                             | G005-5         | 62   |
| XCVR Assembly Diagram   | G005-6         | 63   |
| DELNI Box Mounting (Single or Double)                         | G005-7         | 64   |
| DELNI Mounting Brackets                                       | G005-8         | 65   |
| ODS 318 Fiber Optic Multiplexer To LAN Protocol Translator    | G068-1         | 66   |
| *Fiber Optic Distribution Rack Lightguide Cross-Connect (LGX) | G289-1         | 67   |
| Fiber Optic Connector/Cable Cross Reference                   | G395-1         | 68   |
| Fiber Optic Connector Polishing                               | G395-2         | 69   |
| Fiber Optic Connector Related Losses.                         | G395-3         | 70   |
|   |                |      |

| Title Category 08 – Audio  | <b>Drawing Number</b> | Page |
|--|-----------------------|------|
| AN/FTC-54 Remote Distribution Panel                              | H345-1                | 71   |
| AN/FTC-54 Cable Fabrication                                      | H345-2                | 72   |
| Audio/Intercom Interface (AIU) Cable Fabrication and Signal Flow | H345-3                | 73   |
| AN/FTC-54 Remote Distribution Panel Fabrication Details          | H345-4                | 74   |
| AN/FTC-54 Remote Distribution Panel Fabrication Details          | H345-5                | 75   |
| AN/FTC-54 I/O Assy Jacks-to-PABX Line Cards Correlation Tables   | H345-6                | 76   |
| Title Category 09—Time   | <b>Drawing Number</b> | Page |
| AN/GSQ-216 I/O Cable Fabrication Details                         | I011-1                | 77   |
| AN/GSQ-216 BCD Cable Fabrication Details                         | I011-2                | 78   |
| AN/GSQ-216 to NSP Through ODS-318                                | I023-1                | 79   |
| TRC-703 Time Code Reader Ceiling Installation Details            | I030-1                | 80   |
| TRC-703 Time Code Reader Ceiling Power Installation              | 1030-2                | 81   |
| Single Nixie Indicator Mount for Ceiling Suspension              | I171-1                | 82   |
| Jumper Cable for Nixie Indicator                                 | I270-1                | 83   |
| Time Distribution Junction Box Installation Detail               | I330-1                | 84   |
| Time Distribution Terminal Board Wiring                          | I330-2                | 85   |
| Time Distribution Junction Box Typical Installation              | I330-3                | 86   |
| Title Category 10—RF Panels and Devices                          | <b>Drawing Number</b> | Page |
| CON-6AB Switch Panel   | J117-1                | 87   |
| TV-50 Mounting Panel   | J127-1                | 88   |
| DS-4 Mounting Instructions                                       | J128-1                | 89   |
| BI Directional Coupler Mounting Panel                            | J130-1                | 90   |
| DS-8/DS-309 Power Divider Mounting Panel                         | J149-1                | 91   |
| DS-8/DS-309 Power Divider Mounting Panel                         | J149-2                | 92   |
| BNC Feed Through Panel (1 Inch, 8 Holes Max)                     | J157-1                | 93   |
| C-TYPE Feed Through Panel (1 Inch)                               | J179-1                | 94   |
| RF Connector Cross Reference Table                               | J194-1                | 95   |
| BNC Parallel Networks  | J194-2                | 96   |
| RFD Appearance Panel (3 Inch Steel Panel)                        | J240-1                | 97   |
| B-HJ-320H Power Divider Mounting Panel                           | J298-1                | 98   |
| DA-4FN Video Power Divider Mounting Panel (Frequency Range DCHZ) | J302-1                | 99   |
| Attenuator Mounting Panel (0 dB)                                 | J303-1                | 100  |
| Frequency Mixer Mounting Panel                                   | J304-1                | 101  |
| General Category Feed Through Panel "N" Type Connectors          | J317-1                | 102  |
| Title Category 11—Panel Cutouts/Brackets/Shelves                 | <b>Drawing Number</b> | Page |
| Audio Control Panel  | K010-1                | 103  |
| SSIA-523A Mounting Panel   | K025-1                | 104  |
| Logic Symbols and Pin Identification.                            | K044-1                | 105  |
| Exhaust Fan Mounting Plate (CY-597 Racks)                        | K159-1                | 106  |
| Exhaust Fan Mounting Procedure (CY-597 Racks)                    | K159-2                | 107  |

AIAH 33-102 30 NOVEMBER 2000 5

| AIAH 33-102 30 NOVEMBER 2000                                    |                       |      |
|---|-----------------------|------|
| Exhaust Fan Mounting Procedure (Solid one piece rack tops)      | K159-3                | 108  |
| LS-215 Speaker Mounting Panel with Wiring                       | K176-1                | 109  |
| LS-215 Speaker Mounting Panel with Wiring                       | K176-2                | 110  |
| R-2174 Audio Interface Panel                                    | K316-1                | 111  |
| Title Category 12—Recorders/Recording Devices                   | <b>Drawing Number</b> | Page |
| 1508 Visicorder to Galvo Amp Wiring                             | L187-1                | 112  |
| TNH-25& TNH-21 Foot Switch Assembly Details                     | L280-1                | 113  |
| Remote Switches for TNH-25/21, PT-6, GS-80 Panel Wiring Details | L294-1                | 114  |
| Remote Switch Panel Back Panel Cover                            | L294-2                | 115  |
| SSHM-276-000321 Relay Assembly                                  | L294-3                | 116  |
| SSHM-276/TNH-25   | L294-4                | 117  |
| Optional Inputs To SSHM-276                                     | L294-5                | 118  |
| HP-3964 Recorder Foot Switch Assembly Details (Playback Only    | L307-1                | 119  |
| TNH-25 Recorder Monitor Panel (Dual Jack Blocks)                | L319-1                | 120  |
| Recorder Monitor Jackstrip                                      | L320-1                | 121  |
| Title Category 13—Cabinets, Consoles, and Racks                 | <b>Drawing Number</b> | Page |
| 3B2-600 FRONT PANEL RAISED FLOOR                                | M032-1                | 122  |
| 3B2-600 Cable Shield Construction                               | M032-2                | 123  |
| 3B2-600 Bracket and Floor Mounting Details                      | M032-3                | 124  |
| 3B2-600 FRONT PANEL HARD FLOOR                                  | M032-4                | 125  |
| SUN 56-inch Cabinet   | M062-1                | 126  |
| Typical AN/FYQ-67 Console Installation Details                  | M283-1                | 127  |
| Typical AN/FYQ-67 Console Installation Details                  | M283-2                | 128  |
| *EMCOR Series 10 Rack (Shelves & Power Strip)                   | M288-1                | 129  |
| EMCOR Shelf Mounting and Support Bracket Locations              | M288-2                | 130  |
| EMCOR Series 10 Rack (Anchoring, Grounding)                     | M288-3                | 131  |
| EMCOR Series 10 Rack Overhead Power and Signal                  | M288-4                | 132  |
| Title Category 14 –DELETED                                      |                       |      |
| Title Category 15—Cable, Conduit, and Ducting                   | <b>Drawing Number</b> | Page |
| BOX MODIFICATION FOR WIREMOLD G3000                             | O019-1                | 133  |
| General Purpose AC Power Installation                           | O053-1                | 134  |
| General Purpose AC Power Installation                           | O053-2                | 135  |
| Large Cable Chute for RFD                                       | O172-1                | 136  |
| Typical Overhead Grid and Cable Trough Installation             | O253-1                | 137  |
| Methods of Suspending Channel                                   | O253-2                | 138  |
| Channel Grid and Cable Trough Hanger                            | O253-3                | 139  |
| Double Cable Trough Installation                                | O253-4                | 140  |
| Cable Trough System   | O253-5                | 141  |
| Joining New Cope Trough to Old Cope Trough                      | O253-6                | 142  |
| Local Area Network Ducting and Hardware Application             | O253-7                | 143  |
| Station Ground Installation                                     | O254-1                | 144  |


| Desk/Table Ducting General Purpose<br>EMCOR 10 Series Cable Routing Details<br>EMCOR 10 Series Rack RFD Preparation<br>Standard Box Flange and Wall Mounting  | O326-1<br>O344-1<br>O344-2<br>O346-1   | 145<br>146<br>147<br>148   |
|---|--|--|
| Title Category 16—Power   | <b>Drawing Number</b>  | Page   |
| Ground Fault Circuit Interrupter Outlet Panel *Raised Floor Rack Power Details *Overhead Rack Power Details Duplex Outlet Wiring *Raised Floor Power Details General Procedure and Required Material Securing Flex Conduit Below Raised Floor *Modular Furniture Power Installation External Power Outlet Panel External Power Outlet Panel Raised Floor Service Fittings Fab Kit(s) (Service Box) *Raised Floor Service Fittings Fab Kit(s) (Access Floor Module) Raised Floor Twist Lock Power Service Fitting Raised Floor Service Fittings (Liskey Box) | P004-1<br>P018-1<br>P018-2<br>P266-1<br>P328-1<br>P328-2<br>P332-1<br>P335-1<br>P335-2<br>P342-1<br>P342-2<br>P342-3<br>P342-4 | 149<br>150<br>151<br>152<br>153<br>154<br>155<br>156<br>157<br>158<br>159<br>160 |
| *Raised Floor Service Fittings Fab Kit(s) (Workstation Module) Raised Floor Service Fittings Fab Kit(s) (Workstation Module) Typical Facility Power and Grounding System For Raised Floor Raised Floor Power Detail - Plug Strip Installation In General  | P342-5<br>P342-6<br>P350-1<br>P352-1   | 162<br>163<br>164<br>165   |


CHARLES G. CRAWFORD, Colonel, USAF Director of Logistics

Attachment 1

Engineering and Installation Standard Drawings







IN PROXIMITY TO GROUNDED METAL CONDUIT PATHWAYS

TRANSFORMERS & ELECTRIC MOTORS

FLUORESCENT LIGHTING

17. 1439

18. 1392

19. 1428

MODULE JACK, 110, SHIELDED, RJ45 EIA T568B

CABLE, CAT 5, NON-PLENUM, 4 PAIR UNSHIELDED

RACEWAY, NON-METALIC SELF-ADHESIVE NOT SHOWN

AS REO

AS REO

AS REQ

SIZE DATE ESTABLISHED

Ful

14 MAR 97

J. Davis

J. Davis

DRAWING CONTROL # 029

PROVED

40 IN 40 IN


12 IN 12 IN


40 IN


12 IN


IRAVING NUMBER


99-01-029




















































4






















3 00835 BNC CONN

5 00834 SMC CONN

7 01324 TERMINAL LUG

4 00417 CONNECTOR, MS27467T15F35S

6 00556 BACKSHELL M85049/49-2-14A 6 EA

8 00612 WIRE, 22AWG, STRANDED, BLK 2 FT

NOTE 3

6 EA

NOTE 3

2 EA

37

DF Mux and Gonio Matrix

99-02-343

2

BATE 6 JAN 97 SHEET 2 DF 2

SIZE DATE ESTABLISHED DRAYING NUMBER

C 1 AUG 91


C. Smith


APPROVED


D. Duff


P. M. Spalenka


DRAWING CONTROL # 393

















ENGINEER

2

F, W. Wood PPROVED

D. Duff

DRAVING CONTROL # 325

SIZE DATE ESTABLISHED DRAWING NUMBER


1 SEP 81

99-06-325


DATE 06 JAN 97 SHEET 2 DF 5


С


WIELLIGENCE KOL




















G005-2

# COAXIAL SEGMENT CABLE

- THE MAXIMUM LENGTH OF EACH CDAXIAL SEGMENT IS 500 M (1,640 FT) MADE FROM DIM EHDMIGENEDUS LENGTH OF CABLE. THERE IS NO MINIMUM LENGTH FOR A SECHENT IF A LARGE SEGMENT CANNOT BE MADE FROM DIM. CONTINUOUS LENGTH OF CABLE, THEN THE PIECES WILL BE 23.4 M (76.77 FT), 70.2 M (230.30 FT), UR 177 M (580.7 FT) + 7.5 M (1,64 FT). IF A SPLICE IS REQUIRED, THE 82 FT DISTANCE BETWEEN TAP POINTS MUST BE MAINTAINED TO KEEP LINE LIDSS TO A MINIMUM THESE LENGTHS MATCH 1/4 WAVE LENGTH OF THE DATA RATE AND IS REQUIRED TO MINIMIZE LIDSS. ANY COMBINATION OF THESE PIECES CAN BE USED TO MAKE A CDAXIAL SEGMENT NOT TO EXCEED 500 M.
- BOTH ENDS OF THE SEGMENT VILL BE TERMINATED WITH A 50 OHM N TYPE TERMINATOR AT A TAP POINT. THE CONNECTOR AND TERMINATOR VILL BE INSULATED FROM GROUND AND ONE END ONLY WILL BE CONNECTED
- THE MINIMUM BEND RADIUS OF THE CABLE IS 10 TIMES THE CABLE DAMETER. FOR BELDEN CABLE P/N 89980 WHICH HAS AN OLD. OF 375 INCHES, THE MINIMUM BEND RADIUS IS 3.75 INCHES.
- 4. THE MAXIMUM NUMBER OF SEGMENTS BETWEEN TWO DEVICES IS 5 (REPEATER SEGMENTS COUNT AS A SEGMENT). FOR EXAMPLE: FOR WIST ON COMAINA SEGMENT I TO TAKE TO WSS ON CONSTANT. SEGMENT 3, COMMUNICATIONS IS THOU THE MAXIMUM NUMBER OF SEGMENTS WHICH IS 5. SEGMENT 1, \* REPEATER SEGMENT 1 \* BACKBOIMS SEGMENT \* REPEATER SEGMENT
- A MAXIMUM OF 100 TRANSCEIVERS CAN BE ATTACHED TO A CDAXIAL SEGMENT (THIS INCLUDES THE TRANSCEIVERS USED FOR THE REPEATER). THE TRANSCEIVERS WILL BE ATTACHED AT THE MARKS ON THE COAXIAL SEGMENT WHICH ARE SPACED 2.5 M (82 FT) APART.

### REPEATER SEGMENT

- 1. A REPEATER SEGMENT IS USED TO CONNECT TWO OR MORE COAXIAL SEGMENTS TO MAKE A MAXIMUM TRUNK CARLE 2.5 KM IN LENGTH.
- NUMBER OF SEGMENTS IN THE TRANSMISSION PATH.
- SHIELDED PAIR CABLE WITH OVERALL SHIELD AND WILL HAVE 15 PIN MINIATURE D TYPE CONNECTORS WITH LATCH AND POST.
- MOUNTED IN A EMCOR RACK, TWO REPEATERS CAN BE MOUNTED ON A SINGLE SHELF. IF A RACK IS NOT AVAILABLE IN THE AREA WHERE THE REPEATER IS TO BE MOUNTED, A RACK OR ENCLOSURE WILL HAVE TO BE INSTALLED. IT IS UP TO THE ENGINEER TO DETERMINE WHAT IS TO BE USED (RACK OR ENCLOSURE) AND WHERE IT IS TO BE PLACED.

### ATTACHMENT SEGMENT

- THE ATTACHMENT CABLE WILL USE CABLE WITH INDIVIDUALLY SHIELDED PAIRS WITH OVERALL BRAIDED SHIELD WITH A MAXIMUM LENGTH OF 48 M.
- THE CABLE CAN EXTEND NO MORE THAN 6 FEET ABOVE RAISED FLOOR OR 6 FEET FROM EXIT FROM DUCT, CONDUIT, OR WIRE MOLD. THE CABLE WILL BE INDIVIDUALLY SHIELDED PAIRS WITH AN OVERALL BRAIDED SHIELD.
- THE ATTACHMENT CABLE WILL BE CONNECTED TO THE COAXIAL SEGMENT USING A TRANSCEIVER THAT WILL BE CONNECTED TO THE CLOSEST TAP POINT ON THE COAXIAL SEGMENT.
- IF A PIECE OF EQUIPMENT IS REMOVED THEN THE ATTACHMENT CABLE VILL ALSO BE REMOVED. WHEN EQUIPMENT IS REMOVED FOR MAINTENANCE A DUMMY PLUG VILL BE INSTALLED OR CABLES VILL BE TERMINATED INTO AN ETHERNET DEVICE CSEE SH 4 FIG. 7).

## HUB (DELNI)

- 1. THE PURPOSE OF THE HUB IS TO SUPPLY UP TO EIGHT EQUIPMENT DROPS FROM A SINGLE TAP WHERE THERE IS A HIGH DENSITY OF TERMINALS IN A SMALL AREA AND IT IS IMPRACTICAL TO USE INDIVIDUAL XCVR FOR EACH TERMINAL. EXAMPLE: A ROOM 10 X 15 HAS 8 TERMINALS AND ONLY 2 TAP POINTS ON THE COAXIAL CABLE. A HUB WOULD BE REQUIRED IN THAT ROOM.
- 2. THE HUB IS NOT AN FCC TYPE B DEVICE. IT MUST BE MOUNTED IN AN RFI ENCLOSURE OR RACK. IF IT IS NOT POWERED BY TECH POWER, POWER LINE FILTERS WILL BE REQUIRED.
- 3. IT IS RECOMMENDED THAT ONLY 4 OF THE 8 PORTS ON EACH HUB BE USED. THIS WILL ALLOW FOR FUTURE EXPANSION.
- 4. IT IS RECOMMENDED THAT ONLY WORKSTATIONS THAT ARE HEAVILY USED BE CONNECTED TO A HUB BECAUSE OF ITS ARCHITECTURE. THE HUB WILL ACCESS THE LAN MUCH MORE OFTEN THAN A SINGLE WORKSTATION ON A XCVR.

## FIBER OPTICS LINK

- THE FIBER OPTIC LINK IS USED TO CONNECT REMOTE SEGMENTS OR AS A BRIDGE BETWEEN DIFFERENT LAN SYSTEMS. CONNECTIONS ARE MADE FROM RED INPOTS ON BRIDGE TO BLACK OUTPUTS ON REPEATER; AND BLACK OUTPUTS ON REPEATER.

  ON BRIDGE TO RED INPOS ON REPEATER.
- 2. THE BRIDGE OR REPEATER UNITS WILL BE MOUNTED IN A RACK OR RFI ENCLOSURE. IF IT IS NOT POWERED THROUGH TECH POWER, POWER LINE FILTERS WILL BE REQUIRED.

#### 3B2-600 TO XT

1. THE IBM/XT IS A DOS MACHINE AND CANNOT BE CONNECTED TO THE LAN SYSTEM BECAUSE THE LAN SOFTWARE RUNS UNDER ZENIX OPERATING SYSTEM.

UPDATED DRAWING NUMBERS IN NOTES 7 JAN 97

- 2. THE XT CAN DNLY BE CONNECTED TO THE 3B2-600 CONPUTER USING MIL-188 CONNECTION.
- 3. WHEN THE XT IS DISCONNECTED FROM THE CABLE, THE CABLE WILL BE DISCONNECTED AT BOTH ENDS OR A DUMMY PLUG MUST BE INSTALLED DIN THE UNTERMINATED END OF THE CABLE OR CONNECTOR BOX CSEE SH 4
- 4. THE 3B2-600/G IS MOUNTED IN A TEMPESTED CABINET. ANCHOR TO FLOOR IAW 99-13-032.



PPROVED J. Davis DRAWING CONTROL # 005

WIELLIGENCE AU

29 Jan 88 DATE 30 Dec 96 SHEET 2 DF 8

2. REPEATER SEGMENTS WILL COUNT TOWARDS THE TOTAL


3. THE REPEATER SEGMENT CABLE WILL BE MADE USING INDIVIDUALLY


4 THE REPEATERS WILL BE MILINTED IN A RACK DR ENCLUSURE WHEN


5. THE Y39A REPEATERS HAVE TWO CONNECTORS ON THE BACK: JI (LEFT PORT) TO BACKBONE J2 (RIGHT PORT) TO SEGMENT


SIZE DATE ESTABLISHED DRAWING NUMBER R S Galus 99-07-005


4














ADDED SHEETS 2 AND 3.
MOVED FROM CATEGORY 17 ADDED
CABLE AND CONNECTOR DETAIL AND
UPDATED STEPS AND NOTES. ADDED NOTE 10. LIPDATED FIGURES AND TARGE ES99-001 ADDED CABLE TIES

2M9 AP PMS 7 JAN 97 TMH 9 MAR 98 PMS 25 AUG 98 IN

G395-1

|            | CONNECTORS |      |         |                |    |  |  |  |
|------------|------------|------|---------|----------------|----|--|--|--|
| TYPE       | MODE       | L/I  | FURRULE | FIBER OD/CABLE | OD |  |  |  |
| SMA/Epoxy  | MULTI      | 0987 | METAL.  | 125uM/3.0MM    |    |  |  |  |
| SMA/Epoxy  | MULTI      | 6311 | METAL   | 125uM/3.0MM    |    |  |  |  |
| ST/Epoxy   | MULTI      | 0988 | CERAMIC | 125uM/3.0MM    |    |  |  |  |
| ST/Epoxy   | MULTI      | 1223 | METAL   | 125uM/3.0MM    |    |  |  |  |
| ST/HotMelt | MULTI      | 1216 | CERAMIC | 125uM/3.0MM    |    |  |  |  |
| SC/HotMelt | MULTI      | 1430 | CERAMIC | 125uM/3.0MM    |    |  |  |  |


4

| CABLES    |       |      |        |                    |  |
|-----------|-------|------|--------|--------------------|--|
| Dual, Zip | MULTI | 1227 | Plenum | 62.5/125uM//2.44MM |  |
| Dual, Zip | MULTI | 0989 | Plenum | 50/125uM//2.42MM   |  |


|      | CABLE TIES SEE NOTE 4 |                       |  |  |  |
|------|-----------------------|-----------------------|--|--|--|
| L/I  | P/N                   | DESCRIPTION           |  |  |  |
| 1441 | HLT21-X0              | BLACK VELCRO, 8 INCH  |  |  |  |
| 1444 | HLT21-X2              | RED VELCRO, 8 INCH    |  |  |  |
| 1445 | HLT21-X4              | YELLOW VELCRO, 8 INCH |  |  |  |
| 1450 | HLT31-X0              | BLACK VELCRO, 12 INCH |  |  |  |
| 1456 | HLT31-X2              | RED VELCRO, 12 INCH   |  |  |  |
| 1457 | HLT31-X4              | BLACK VELCRO, 12 INCH |  |  |  |

THE FIBER HOLE IN THE CONNECTOR IS CLEAR.


APPROPRIATE PARTS OF THE CONNECTOR AND CABLE.




FC TYPE



ST TYPE



SC TYPE



#### NOTES:

THE FOLLOWING BASIC GUIDELINES APPLY TO INSTALLATION OF FIBER OPTIC CABLE SEE T.O. 31-10-34 FOR SPECIFIC DETAILS AND FOR CONNECTOR ASSEMBLY METHODS.

- 1. TENSILE LOAD (PULLING FORCE) MUST NOT EXCEED SPECIFIED LIMITS TO AVOID CRACKING OF THE FIBER. PULLING CABLE IN CONDUIT REQUIRES SPECIAL PROCEDURES.
- 2. CABLES MUST NOT BE KINKED IN ANY WAY.
- 3. CABLES MUST NOT BE CRUSHED BY COVERING WITH HEAVY CABLES OR OVER TIGHTENING CABLE
- 4. REDUCE TENSILE LOADS IN VERTICAL CABLE RUNS BY BEGINNING AT THE TOP AND USING CABLE TIES AT REGULAR INTERVALS.
- 5. OBSERVE MINIMUM BEND RADIUS. THIS IS 10 TIMES THE DUTSIDE DIAMETER OF THE CABLE
  AFTER THE CABLE HAS BEEN INSTALLED AND THE TENSILE LOAD HAS BEEN REDUCED. DURING
  INSTALLATION WHEN THE CABLE IS UNDER LOAD, THE BEND RADIUS INCREASES TO 20 TIMES
  THE DIAMETER.
- 6. DO NOT USE CABLES WITH METAL STRENGTH MEMBERS.
- 7. USE PLENUM RATED CABLES IN AIR CONDITIONING OR VENTILATION DUCTS OR SPACES.
- 8. INNER DUCT (LI'S 1207 & 1293) WILL BE USED WHERE FIBER OPTIC CABLE REQUIRES ADDITIONAL PROTECTION SUCH AS INSIDE DUCT AND UNDER RAISED FLOORING.
- INSTALLATION PROCESS CONSIST OF CABLE PREPARATION, CONNECTOR MOUNTING, AND CONNECTOR POLISHING. REFER TO MANUFACTURE'S INSTRUCTIONS TO PERFORM THESE CRITICAL STEPS: A. MEASUREMENTS - EACH TYPE OF CONNECTOR REQUIRES DIFFERENT MEASUREMENTS FOR CABLE INSTALLATION. ALL MEASUREMENTS MUST BE EXTREMELY ACCURATE TO ENSURE THE CONNECTOR IS MOUNTED PROPERLY. B. JACKET SEMDAL - CAREFULLY REMOVE THE JACKET WITHOUT DAMAGING THE FIBER. JACKET STRIPPERS, X-ACTO KNIFE, OR CABLE SHEATH KNIFE MAY BE USED.

CAUTION: EXERCISE EXTREME CARE WHILE USING SHARP-EDGED TOOLS.

C. BUFFER REMOVAL - USE BUFFER STRIPPERS OR CHEMICAL STRIPPER TO CAREFULLY REMOVE THE BUFFER, BEING SURE NOT TO DAMAGE THE FIBER.

D. KEVLAR REMOVAL - USE THE SPLICER'S SCISSORS OR KEVLAR CUTTERS TO TRIM THE KEVLAR TO THE PROPER LENGTH. THE KEVLAR PROVIDES ADDITIONAL STRENGTH BETWEEN THE CABLE AND CONNECTOR. E. FIBER CLEANING - USE ISOPROPYL ALCOHOL AND A LINT-FREE CLOTH TO CAREFULLY CLEAN THE FIBER ALWAYS CLEAN USING DIRE OF TWO ISTROKES FROM THE JACKET TO THE FIBER FROM CLEANING FROM THE FIBER END TOWARD THE JACKET COULD RESOLLT

10. THE FOLLOWING PARAMETERS WILL BE USED FOR TESTING FIBER OPTIC CABLES

CONNECTOR LOSS: 0.5 db PER MATED PAIR :22FL 31 IQ2 0.2 db PER SPLICE

MULTIMODE: 3 db/km @ 850nm, 1 db/km @ 1300nm FIRER LITSS:

SINGLEMODE: 0.4 dlo/km @ 1310nm, 0.4 dlo/km @ 1550 nm

## UNTIL THE EPOXY IS CURED BEFORE ATTEMPTING TO POLISH.

Е

EPOXY CONNECTORS

A. HEAT CONNECTOR IN OVEN — AFTER THE OVEN WARMS UP, PLACE THE CONNECTOR IN A CONNECTOR HOLDER AND PLACE IN THE OVEN FOR ONE MINUTE, AND NO MORE THAN

CONNECTOR MOUNTING — AFTER PREPARATION, THE CABLE MUST BE CAREFULLY MOUNTED ONTO THE CONNECTOR. THE FOLLOWING PREVEN OF THESE PROCEDURES WILL LLUSTRATE THE SIGNIFICANT DIFFERENCES BETWEEN THE EPOXY AND THE HOT MELT TYPE CONNECTORS.


A. INVENTORY AND CLEAN — ENSURE ALL PARTS ARE AVAILABLE AND CLEAN USING ALCOHOL AND COMPRESSED AIR. IT IS PARTICULARLY IMPORTANT TO MAKE SURE

B. APPLY EPOXY - THE EPOXY (LI 1139) MUST BE MIXED AND APPLIED TO THE

C. MOUNT THE FIBER - THE FIBER MUST BE PLACED INTO THE CONNECTOR, BEING CAREFUL NOT TO BREAK IT. IF THE FIBER BREAKS, THE CONNECTION WILL BE LOST.

D. CRIMP THE CONNECTOR - USE CRIMPERS TO CRIMP THE SLEEVE ON THE CONNECTOR BODY, ENSURING THE KEVLAR IS BETWEEN THE SLEEVE AND THE BODY. F CURE THE EPOXY - FACH TYPE OF FPOXY HAS A DIFFERENT CURE TIME WAIT

- B. MOUNT THE FIBER CAREFULLY PLACE THE FIBER IN THE CONNECTOR, IF THE FIBER DOES NOT ENTER EASILY, THE EPOXY HAS NOT HEATED LONG ENOUGH TO ACHIEVE ITS
- C. COOL THE CONNECTOR SECURE THE CABLE IN THE CONNECTOR HOLDER AND PLACE IN THE COOLING STAND. ALLOW THE CONNECTOR TO COOL FOR THREE FOUR MINUTES BEFORE POLISHING.



SAMPLE FIBER OPTICS CABLE AND CONNECTOR

SEE T.O. 31-10-34 FOR CONSTRUCTION DETAILS



CHECKER R. E. Muzz J. Davis WIELLIGENCE AGE J. Davis DRAWING CONTROL # 395

Connector / Cable Cross Reference SIZE DATE ESTABLISHED DRAVING NUMBER

С 1 May 92 99-07-395 SCALE 3 Feb 99 SHEET \_\_\_\_\_ OF \_\_\_3


CLEAVED FIBERS

FIBER CLEAVING — BARE FIBERS MUST BE CUT TO THE PROPER LENGTH FOR SPLICING. NUMEROUS CLEAVING TOUS. ARE AVAILABLE FOR THIS PURPOSE, AND ALL USE THE SCORE AND BREAK METHOD FOR CUTTING FIBERS. SPLICING REQUIRES A CLEAVE VERY CLOSE TO PERFECT, AND IT TAKES PRACTICE AND EXPERIENCE TO ACHIEVE A PERFECT CLEAVE. THE QUALITY OF THE CLEAVES THAN AS GREAT DEALT OD DO WITH THE OVERALL OLDSS OF A FIBER OPTIC LINK. THERE ARE TWO MAIN THINGS TO CHECK FOR WHEN EVALUATING THE QUALITY OF A CLEAVED FIBER.

- A. CHECK THE END SURFACE ANGLE FOR A PERFECTLY SQUARE CUT. DEPENDING UPON THE APPLICATION, ANGLES MEASURING 1 TO 2 DEGREES DIFFERENCE ARE GENERALLY ACCEPTABLE. PROBLEMS MAY ARISE IF A CLEAVE HAS AN ANGLE OF 3 DEGREES OR MORE.
- B. CHECK THE FIBER END FOR SMOOTHNESS AND A LACK OF BLEMISHES SUCH AS THOSE LISTED ABOVE.

EVALUATION OF THE CLEAVED FIBER ENDS CAN BE ACCOMPLISHED BY OBSERVATION THROUGH A MICROSCOPE.


В




- A. CLEAVE THE FIBER CLEAVE FLUSH WITH THE EPOXY BEAD.
- B. COURSE POLISH PERFORM THE COURSE POLISH ON THE RIGHT POLISHING PLATEN FOR ONE MINUTE.
- C. FINE POLISH PERFORM THE FINE POLISH ON THE LEFT POLISHING PLATEN FOR ONE MINUTE.
- D, INSPECTION INSPECT THE SURFACE WITH A MICROSCOPE, AND RETURN CONNECTOR TO THE FINE POLISH FOR SHORT PERIODS OF TIME IF MORE POLISHING IS REQUIRED.


#### 3M HOT MELT

- A. CLEAVE THE FIBER CLEAVE FLUSH WITH THE EPOXY BEAD.
- B. POLISH THE FIBER BEGINNING WITH VERY LIGHT PRESSURE, UNTIL REACHING THE EPOXY. APPLY PRESSURE UNTIL THE EPOXY HAS BEEN REMOVED FROM THE CONNECTOR SURFACE.
- C. INSPECTION PERIODIC AND FINAL INSPECTIONS ARE CONDUCTED USING A MICROSCOPE.




















BATE 8 JAN 97


sнеет 5 ог 6


DRAWING CONTROL # 345










































































































2






















































AIAH 33-102


Attachment 1 30 NOVEMBER 2000
























































FIG. 3

3

RIGHT SIDE VIEW

C. Smith

D. Duff

DRAWING CONTROL # 018

SIZE DATE ESTABLISHED DRAWING MUNBER


99-16-018

10 DEC 99 SHEET \_2\_ DF \_2

C 8 AUG 88

SCALE Full

FIG. 2 TOP VIEW



4

C 15 DEC 81


J. Davis


2


DRAWING CONTROL # 328


99-16-328


DATE 25 AUG 00 SHEET 1 DF 2




















4

